

MBRP

MBRP Muffler Installation Instructions

1140210

2008

REV XP 600 SDI HO

1150210 – 115T209

2009-2018

REV XP 600 E TEC

Note: Local regulations may limit or prohibit modification to your snowmobile's emissions system and/or the sound levels that it generates. It is your responsibility to be aware of restrictions that may apply to your intended use of this product.

1. Remove springs fastening stock muffler to frame and exhaust pipe. (Set springs safely aside so they can be reused)
2. Remove stock muffler.
3. Install MBRP muffler, placing its outlet through the stock exit in the belly pan. The muffler should rest on the aluminum plate protecting the engine.
4. Using stock springs, fasten the MBRP muffler using tabs on inlet pipe.
5. Use the provided spring extensions and stock springs to fasten the muffler body.

NOTE: To avoid exhaust leaks use high heat silicone to seal all connections between expansion chambers and muffler. Monitor for leaks during the first 200 miles after your installation and re-apply silicone where necessary. We suggest having your local snowmobile mechanic or performance shop install this product.

CAUTION: **DO NOT** touch muffler while snowmobile is running or shortly after it has run, as it may result in personal injury.

MBRP Ltd. warranty applies for a two (2) year period from the date of purchase to defects in product material and workmanship and is to the original purchaser on record and for the original vehicle for which it was designed and installed. This warranty is limited, at MBRP Ltd. sole determination, to the repair or replacement of defective product only and does not include the cost of removal or re-installation, damage by accident, abuse, misuse or misapplication or any consequential damages however they may arise. Determination of warranty coverage shall be at the discretion of an authorized MBRP Ltd quality engineer.