

MBRP

POWERSPORTS

Header Installation Instructions

1310600

2016+ Rev XS 1200

Note: Will not fit models with auxiliary Radiator and Fan.

1. Remove springs fastening stock muffler to frame and exhaust pipe. (Set springs safely aside so they can be reused)
2. Remove stock muffler.
3. Remove stock mid pipe and header pipe from machine. Re-install stock muffler in its original location.
4. Ensure stock header gasket is still in the correct position on the engine.
5. Install the MBRP Powersports header assembly, ensuring clamp is on middle pipe.
6. Tighten all hardware.
7. Align the MBRP Powersports header pipe outlet with stock muffler and fasten using stock springs.



NOTE: To avoid exhaust leaks use high heat silicone to seal all connections between pipes and muffler. Monitor for leaks during the first 200 miles after your installation and re-apply silicone where necessary. We suggest having your local snowmobile mechanic or performance shop install this product.

CAUTION: **DO NOT** touch the exhaust while snowmobile is running or shortly after it has run, as it may result in personal injury.

MBRP Powersports warranty applies for a one (1) year period from the date of purchase to defects in product material and workmanship and is to the original purchaser on record and for the original vehicle for which it was designed and installed. This warranty is limited, at MBRP Powersports sole determination, to the repair or replacement of defective product only and does not include the cost of removal or re-installation, damage by accident, abuse, misuse or misapplication or any consequential damages however they may arise. Determination of warranty coverage shall be at the discretion of an authorized MBRP Powersports quality engineer.