

PLEASE READ BEFORE STARTING INSTALLATION

While MBRP Inc. has made every effort to ensure that this component is of superior quality and properly packaged, it is the installer's responsibility to ensure the following before beginning the installation.

- that the component is undamaged.
- that the component you have purchased is appropriate for your vehicle year, model and configuration.
- that the component will not interfere with any modifications previously installed.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this component to your vehicle please contact your dealer before commencing installation.

Installation Instructions for; IT1001

2003-2004 Dodge 5.9L Cummins 24V Flow Adapter



1. Locate the intake silencer



2. Remove the Clamps holding the intake tubes to the silencer. Do not discard the clamps as they are required for the installation of the **Flow Adapter**.



3. Remove the intake silencer.



4. Install the **Flow Adapter** into the intake system using the clamps removed previously.



Congratulations! You are ready to begin enjoying the improved performance and driving experience of your MBRP Inc. **Flow Adapter**. We hope you enjoy your purchase.